

FRONT

PICTURE 1

Part Number 04G3393
Form Number S15F-2246-02

October 22, 1991

EDITION Edition Notice
Safety Information

Refer to the *Hardware Maintenance Reference General Information* pamphlet for the following safety information:

- General Safety
- Electrical Safety.

Third Edition (October 1991)

The following paragraph does not apply to the United Kingdom or any country where such provisions are inconsistent with local law:

INTERNATIONAL BUSINESS MACHINES CORPORATION PROVIDES THIS PUBLICATION "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. Some states do not allow disclaimer of express or implied warranties in certain transactions, therefore, this statement may not apply to you.

This publication could include technical inaccuracies or typographical errors. Changes are periodically made to the information herein; these changes will be incorporated in new editions of the publication. IBM may make improvements and/or changes in the product(s) and/or the program(s) described in this publication at any time.

It is possible that this publication may contain reference to, or information about, IBM products (machines and programs), programming, or services that are not announced in your country. Such references or information must not be construed to mean that IBM intends to announce such IBM products, programming, or services in your country.

Requests for technical information about IBM products should be made to your IBM Authorized Dealer or your IBM Marketing Representative.

IBM may have patents or pending patent applications covering subject matter in this document. The furnishing of this document does not give you any license to these patents. You can send license inquiries, in writing, to the IBM Director of Commercial Relations, IBM Corporation, Purchase, NY 10577.

| Copyright International Business Machines Corporation 1990, 1991. All rights reserved.

Note to U.S. Government Users -- Documentation related to restricted rights -- Use, duplication or disclosure is subject to restrictions set forth in GSA ADP Schedule Contract with IBM Corp.

FRONT_1 Special Notices

References in this publication to IBM products, programs, or services do not imply that IBM intends to make these available in all countries in which IBM operates. Any reference to an IBM product, program or service is not intended to state or imply that only IBM's product, program, or service may be used. Any functionally equivalent product, program, or service that does not infringe any of IBM's intellectual property rights or other legally protectible rights may be used instead of the IBM product, program, or service. Evaluation and verification of operation in conjunction with other products, programs, or services, except those expressly designated by IBM, are the user's responsibility.

IBM may have patents or pending patent applications covering subject matter in this document. The furnishing of this document does not give you any license to these patents. You can send license inquiries, in writing, to the IBM Director of Commercial Relations, IBM Corporation, Purchase, NY 10577.

The following terms, denoted by an asterisk (*) in this publication, are trademarks of the IBM Corporation in the United States and/or other countries:

IBM
Personal System/2
Micro Channel
XP
XGA.

The following terms, denoted by a double asterisk (**) in this publication, are trademarks of the Intel Corporation in the United States and/or other countries:

486
487
SX.

CONTENTS Table of Contents

| | |
|----------|--|
| EDITION | Edition Notice |
| FRONT_1 | Special Notices |
| CONTENTS | Table of Contents |
| 1.0 | Product Description |
| 1.1 | Security |
| 1.1.1 | Cover Lock |
| 1.1.2 | Power-On Password |
| 1.2 | System Features |
| 1.2.1 | Processor Board |
| 1.2.2 | CMOS RAM and CMOS RAM Extension |
| 1.2.3 | IML, POST, and BIOS |
| 1.2.4 | Graphics Array |
| 1.2.5 | Serial Port |
| 1.2.6 | Parallel Port |
| 1.2.7 | Diskette-Drive Controller |
| 1.2.8 | Keyboard Connector and Pointing-Device Connector |
| 1.3 | System Memory |
| 2.0 | Option Compatibility |
| 2.1 | Drive and Diskette Compatibility |
| 2.2 | Hard Disk and Diskette Drives |
| 2.3 | Terminators |
| 3.0 | Operating Requirements |
| 3.1 | Power Supply |
| 4.0 | Reference Diskette |
| 4.1 | Installing a New Version of the Reference Diskette |
| 4.2 | Making a Backup Copy of The System Partition |
| 4.3 | Diagnostic Programs and Information |
| 5.0 | Specifications |
| 6.0 | Special Tools |
| 7.0 | Removals and Replacements |
| 7.1 | 1005 Cover and Front Bezel |
| 7.2 | 1010 Cover Lock |
| 7.3 | 1015 Drive Retainer and Bezels |
| 7.4 | 1020 Information Panel Assembly |
| 7.5 | 1025 Diskette Drive |
| 7.6 | 1030 Hard Disk Drive |
| 7.7 | 1035 Adapters and Adapter Guide |
| 7.8 | 1040 487SX Processor (extended math capability) |
| 7.9 | 1045 Power Supply |
| 7.10 | 1050 Memory Module Kit |
| 7.11 | 1055 Battery |
| 7.12 | 1060 System Board |
| 7.13 | 1065 Adapter Retainer and Ground Assembly |
| 7.14 | 1070 Rear Bezel |
| 7.15 | 1075 Drive Support Structure |
| 7.16 | 1080 Access Cover Fan |
| 7.17 | 1085 Access Cover Fan Cable |
| 7.18 | 1090 Option Hardware Trays |
| 7.19 | 1095 Pedestal |
| 8.0 | Locations |
| 8.1 | Front View |
| 8.2 | Rear View |
| 8.3 | Interior View |
| 8.4 | Internal Cables |
| 8.5 | System Board |
| 8.6 | Processor Board |
| 9.0 | Grounds |

1.0 Product Description

The IBM (*) Personal System/2 (*) Model XP (*) 486 computers use the IBM Micro Channel (*) architecture. The features of the various types of the Model 95 are:

- Security
 - Cover lock
 - Power-on password
- System board
 - Processor board (with a connector for L2 Cache)
 - 80486 25-MHz processor board (math capability built in)
 - 80486 33-MHz processor board (math capability built in)
 - 80486 50-MHz processor board (math capability built in)
 - Processor board (without a connector for L2 Cache)
 - 80486SX (**) 20-MHz processor board (without math capability)
 - 80487SX (**) 20-MHz processor board (math capability built in)
 - 80486SX 25-MHz processor board (with an empty socket for an 80487SX processor with math capability)
 - 64 byte complementary metal-oxide semiconductor (CMOS) random access memory (RAM) with real-time clock and 2KB (KB = 1024 bytes) CMOS RAM extension.
 - A minimum of 4MB (MB = 1 048 576 bytes) random access memory (RAM) (64MB total system memory capacity)
 - Graphics array
 - Extended graphics array (XGA) (*) with 512KB expandable to 1MB
 - Video graphics array (VGA) compatible
 - Eight 32-bit expansion slots
 - Six 32-bit expansion slots with matched memory extension
 - Two 32-bit expansion slots with auxiliary video extension
 - Serial port
 - Parallel port
 - Diskette-drive controller
 - Battery (to keep CMOS RAM active when power is off)
 - Keyboard connector
 - Initial Machine Loading (IML) supported
 - Pointing-device connector
- Power supply
 - Switchable to the 100-125 V ac or the 200-240 V ac range
 - 50 or 60 Hz
- Speaker
- Information panel
- Small Computer System Interface (SCSI) adapter with internal and external connectors
- 101/102-key keyboard
- SCSI fixed disk drive (hard disk drive)
- Diskette drive.

(*) IBM, Personal System/2, Micro Channel, XGA, and XP are trademarks of the International Business Machines Corporation.

(**) 486, 487, and SX are trademarks of the Intel Corporation.

Subtopics

- 1.1 Security
- 1.2 System Features
- 1.3 System Memory

1.1 Security

Subtopics

1.1.1 Cover Lock

1.1.2 Power-On Password

1.1.1 Cover Lock

The cover lock is on the front panel of the system unit. The lock secures the front bezel and side cover and can be unlocked with the user's key.

If the keys for the cover lock are lost, order a new cover lock assembly. (See the Parts section in the *Hardware Maintenance Service* pamphlet). The new assembly contains two keys. Use a pair of pliers with one of the new keys to force the old cover lock open.

1.1.2 Power-On Password

A power-on password denies access to the system by an unauthorized user when the system is powered-on. When a power-on password is active, the password prompt (which resembles a small key) appears on the screen each time the system is powered-on (except when the system is in the Unattended Start Mode). Access to the system occurs when the proper password is entered.

To service a system with an active and unknown power-on password, power-off the system and do the following:

1. Locate connector J16 on the system board (see "System Board" in topic 8.5 for connector location).
2. Move the jumper on J16 so that it connects the center pin and the pin on the opposite end of the connector.
3. Power-on the system.

The system detects the change and the password is erased from memory. Leave the jumper in that position until the next time you need to reset the password.

To reinstall a password, the user must start the system, select **Set features** from the Main Menu and follow the instructions.

1.2 System Features

The major features of the system are:

- Processor board
- CMOS RAM
- Initial Machine Loading (IML)
- Basic Input/Output System (BIOS)
- Power-on Self-Test (POST)
- Graphics array (VGA and XGA) adapter
- Serial port
- Parallel port
- Diskette-drive controller
- Keyboard connector
- Pointing-device connector.

Subtopics

- 1.2.1 Processor Board
- 1.2.2 CMOS RAM and CMOS RAM Extension
- 1.2.3 IML, POST, and BIOS
- 1.2.4 Graphics Array
- 1.2.5 Serial Port
- 1.2.6 Parallel Port
- 1.2.7 Diskette-Drive Controller
- 1.2.8 Keyboard Connector and Pointing-Device Connector

1.2.1 Processor Board

The processor board is connected to the system through two dedicated in-line system-board connectors. The major components on the processor board are the system microprocessor, the system clock, the direct memory access (DMA) controller, and the memory controller.

The system microprocessor is a 32-bit microprocessor that operates in the real-address mode or in the virtual-address (protected) mode.

The amount of memory supported and the clock speed vary with the type of processor board installed.

1.2.2 CMOS RAM and CMOS RAM Extension

CMOS RAM provides 64 bytes of storage. Fifty bytes are used to store system configuration and security information. The real-time clock uses the remaining 14 bytes to track the date, time, and battery level. An 8KB (KB = 1024 bytes) CMOS RAM extension stores additional configuration and system-status information.

The data stored in the CMOS RAM and CMOS RAM extension is kept active by the battery when the system is powered-off. If the stored data is lost due to a depleted or removed battery, the data can be restored using one of the following methods:

- If the user has a customized configuration that uses settings other than the default, run restore configuration from the system programs stored on the hard disk drive.
- If the configuration uses the default settings, run automatic configuration from the system programs stored on the hard disk drive.

1.2.3 IML, POST, and BIOS

The Model 95 uses Initial Machine Load (IML) to store the power-on self-test (POST) and Basic Input/Output System (BIOS) code. With IML, some of the code is stored in ROM and is used for preliminary testing during power-on; but the balance of the POST and BIOS code, called the IML image, is stored in a protected partition on the default hard disk drive. This IML image is loaded onto the default hard disk drive at the time the system is manufactured.

At power-on, the first stage of POST is started from ROM. During this first stage, POST performs the following functions:

- Checks some basic system-board and processor-board functions
- Initializes the video function
- Checks the memory subsystem
- Verifies that the default hard disk drive is functioning
- Verifies that the IML image is copied in the protected partition of the hard disk drive.

When the first stage of POST is complete, the IML image is loaded into RAM from the protected partition on the default drive. The second stage of POST is started from RAM. It performs additional tests of the hardware and initializes the system. When the second stage of POST is complete, system control is given to the operating system.

The partition also includes the system system programs and the customer and advanced diagnostic programs. The partition is not affected when the drive is formatted using the operating system Format command.

Errors During POST: If the POST detects a problem, an eight-digit error code is displayed.

Replacing the Default Hard Disk Drive: If you replace the default hard disk drive, you must recopy all of the files onto the replacement hard disk drive. To recopy the files:

1. Start the system using the customer's *backup copy* of the current system partition.

Warning: Before you do this, you must either have a *complete current backup copy* of the system partition or all of the option diskettes so you can recopy the option files.

2. Select **Backup/Restore system programs** from the Main Menu.
3. Run the **Restore System Partition** option to load the IML image, the system programs, and the customer and advanced diagnostic programs onto the default hard disk drive.

Notes:

1. If the user's backup copy of the system partition is incomplete, you will not completely restore the system partition. If this is the case, after you have recopied the IML image, get the option diskettes and use **Copy an option** to recopy the option files onto the system partition.
2. If the IML image has been loaded onto the hard disk drive, but the customer's operating system has not been loaded, the Insert Diskette icon will appear on the display.

For information on system programs, see the *Diagnostic Information for Micro Channel Computers* pamphlet.

1.2.4 Graphics Array

The graphics array is located on the XGA Display Adapter/A and operates in two video modes:

1. VGA compatibility mode
2. XGA compatibility mode.

The adapter comes with four video-memory modules (512KB) installed. Four additional sockets are available for installing additional video-memory modules (maximum video memory is 1MB). When the system is powered-on, the graphics array is in the VGA mode. In this mode, all VGA alphanumeric text, and all-points-addressable (APA) graphics video modes are supported. The maximum resolution in VGA compatibility mode is 720-by-400 picture elements (PELS) in the text mode, and 640-by-480 PELS in the graphics mode. A maximum of 256 colors or 64 shades of gray is supported in VGA mode. Composite video is not supported.

The graphics array is in the XGA mode only when enabled by the DOS Adapter Interface or video device driver (example: MS Windows, OS/2 Presentation Manager device drivers).

The XGA works with monochrome and color-analog direct-drive displays.

XGA supports the following:

| Adapter Video Memory | Resolution | Colors |
|--------------------------------------|-------------------------------|--------|
| Four video modules installed (512KB) | 640 x 480 or 1024 x 768 | 256 16 |
| Eight video modules installed (1MB) | 640 x 480 | 256 |

1.2.5 Serial Port

The serial port is fully programmable and supports asynchronous communications. The 25-pin, D-shell connector provides the signals to drive a device with a standard 25-contact RS-232 connector. The connected device is identified by the system configuration as SERIAL 1 through SERIAL 8. Adapters with serial ports also can be configured from SERIAL 1 to SERIAL 8. Conflicts occur with multiple communication lines if two or more lines have the same address. Select the **Set configuration** option from the system programs on the hard disk drive. Select **View Configuration** to verify that no lines are addressed the same.

1.2.6 Parallel Port

The parallel port allows the attachment of devices that accept eight bits of parallel data at standard transistor-transistor logic (TTL) levels. The port has a 25-pin, D-shell connector and is designed primarily for printers. However, the port can be used as an input/output port for any device or application that matches the input/output capabilities of the port. When adapters with additional parallel ports are installed, the system can support three devices, each addressed separately as PARALLEL 1, PARALLEL 2, or PARALLEL 3.

Note: Conflicts occur when using multiple devices if two or more devices are addressed the same. Select the **Set configuration** option from the system programs on the hard disk drive. Select **View configuration** to verify that no lines are addressed the same.

1.2.7 *Diskette-Drive Controller*

The controller connects to the diskette drives through a single 40-pin cable on the system board. Signals and voltages are supplied through the diskette-drive cable that plugs into the connector. These signals and voltages can operate two 3.5-inch diskette drives and one 5.25-inch drive.

1.2.8 Keyboard Connector and Pointing-Device Connector

The two 6-pin connectors on the rear of the system board are for a keyboard and a pointing device (mouse). The keyboard connector is marked with a small keyboard figure molded into the back panel; the unmarked connector is for a pointing device. The interface logic is the same for both.

1.3 System Memory

The figure below shows the location of the memory-module-kit connectors B1 to A4 on the system board.

PICTURE 2

The system board has eight connectors for system-board memory-module kits. The system can support up to 64MB of memory on the system board, but the amount of memory accessed may be limited by the operating system.

Memory Requirements and Limitations: Whenever memory is added or removed from the system, run **Set Configuration** from the Main Menu. If memory failed and then the customer runs customer diagnostics, the advanced diagnostics will not detect the failing memory. After defective memory is replaced, run the advanced diagnostic memory test or the system will not recognize the replacement memory.

The memory operates differently depending on which processor board is installed. Systems can be upgraded with a different processor board than the type indicated on the system serial number label. To verify which board is installed, you must start the system programs and select **Display Revision Levels** from the Main Menu. Make note of the submodel code displayed on the screen.

The following indicates the memory configurations supported and which system memory section to refer to.

| Submodel Code | Interleaved Supported | Noninterleaved Supported | System Memory Type |
|---------------|-----------------------|--------------------------|--------------------|
| 14 | Yes | No | Type 1 |
| 16 | Yes | No | Type 1 |
| 2C | Yes | No | Type 1 |
| 2E | Yes | No | Type 1 |
| 2A | Yes | No | Type 1 |
| 58 | Yes | Yes | Type 2 |
| 5A | Yes | Yes | Type 2 |

Interleaved Memory: An interleaved-memory configuration requires matched pairs of memory-module kits (the size and the speed must be the same). The kits must be installed in the following order: (starting with the J11 memory-riser card) pair J1, J3 then pair J2, J4. and so forth. This technique of addressing memory in pairs enhances performance.

Noninterleaved Memory: A noninterleaved-memory configuration does not require matched pairs of memory-module kits (the size and speed does not have to be the same). Noninterleaved memory runs less efficiently than interleaved memory but will allow mixed sizes of memory to be used.

Type 1 systems support interleaved-memory configurations only.

Type 2 systems support interleaved, noninterleaved, or a combination of both configurations.

Memory Errors (Type 1 Systems): Some memory errors will cause a blank display screen. If the display screen is blank, the only indication of a failure will be the POST error code displayed on the information panel. The factory-installed 2MB kits (pair A1 and B1) are divided into two banks and are addressed as follows:

- The first 1MB bank of A1 and the first 1MB bank of B1 are the first block
- The second 1MB bank of A1 and the second 1MB bank of B1 are the second block.

Any other pairs of memory-module kits (for example A2, B2,) are addressed in the same way; however, the block size depends on the memory kits installed.

When any defective memory is detected in a bank, the entire block is disabled.

The following figure shows an example of how memory disabling (after a memory failure) varies depending on the memory configuration.

| Paired Memory | Memory Bank Size | Memory Block | Memory Now |
|---------------|------------------|--------------|------------|
|---------------|------------------|--------------|------------|

| Kits | | | | Disabled | Usable |
|------|-----|-----|-----|----------|--------|
| A1 | B1 | A1 | B1 | | |
| 1MB | 1MB | 1MB | 1MB | 2MB | 0MB |
| 2MB | 2MB | 1MB | 1MB | 2MB | 2MB |
| 4MB | 4MB | 4MB | 4MB | 8MB | 0MB |
| 8MB | 8MB | 4MB | 4MB | 8MB | 8MB |

Minimum-memory-block size is 2MB for 1MB and 2MB memory-module kits and 8MB for larger memory-module kits.

Note: If a system with only two 1MB kits (one 2MB block) or two 4MB kits (one 8MB block) installed detects a memory problem, all system-board memory will be disabled. (These are not standard configurations and should be avoided.)

If the POST detects an error in the first block of system-board memory, that block is disabled. If additional system-board memory is installed, the addresses assigned to the deactivated blocks are reassigned to the next usable block of system-board memory and a POST error code is displayed.

If an additional block of system-board memory is installed, the customer-level diagnostic programs (on the default hard disk drive) can be run to deactivate the defective block and reassign the memory addresses. The system can then operate with reduced memory capacity. The defective block will then be ignored by POST during subsequent power-on operations.

If an additional block of system-board memory is *not* installed, no address reassignment can occur and the system can't be used.

Memory Errors (Type 2 Systems): Some memory errors will cause a blank display screen. If the display screen is blank, the only indication of a failure will be the POST error code displayed on the information panel.

If the memory is installed in an interleaved configuration, the system will operate as described under Memory (Type 1 systems); however, memory errors are handled differently. If an error occurs in an interleaved memory configuration, the pair of memory module kits containing the error will automatically be switched to noninterleaved operation to keep the maximum amount of memory active. Only the failing *bank* of memory will be disabled.

The following figure shows how the amount of memory that is disabled varies depending on the size of the memory-module kit installed.

| Memory Module Kit installed | Memory Bank Size Disabled |
|-----------------------------|---------------------------|
| 2MB | 1MB |
| 4MB | 4MB |
| 8MB | 4MB |

Note: If a system with only one 1MB kit or one 4MB kit installed detects a memory failure, all system-board memory will be disabled. (These are not standard configurations and should be avoided.)

If the POST detects an error in the first bank of system-board memory, that bank is disabled. If additional system-board memory is installed, the addresses assigned to the deactivated banks are reassigned to the next usable bank of system-board memory and a POST error code is displayed.

If an additional block of system-board memory is installed, the customer-level diagnostic programs (on the default hard disk drive) can be run to deactivate the defective bank and reassign the memory addresses. The system can then operate with reduced memory capacity. The defective bank will then be ignored by POST during subsequent power-on operations.

If an additional block of system-board memory is *not* installed, no address reassignment can occur and the system can't be used.

2.0 Option Compatibility

The Model 95 uses only those adapters that are specifically designed for it. All supported 16-bit and 32-bit adapters operate in any system-board expansion slot. For supported options, see the Parts section in the *Hardware Maintenance Service* pamphlet for the system you are servicing.

Subtopics

- 2.1 Drive and Diskette Compatibility
- 2.2 Hard Disk and Diskette Drives
- 2.3 Terminators

2.1 Drive and Diskette Compatibility

The following provides information concerning the identification of diskette drives.

| Diskette Drive | Identifying Mark |
|-------------------|--------------------------|
| 3.5 Inch - 720KB | None |
| 3.5 Inch - 1.44MB | 1.44 on the Eject Button |

The following addresses the compatibility of diskettes to diskette drives.

| Diskette Capacity | 720KB Drive | 1.44MB Drive |
|-------------------|----------------|--------------|
| 1.0MB | Read/Write | Read/Write |
| 2.0MB | Not Compatible | Read/Write |

Notes:

- For additional information, see "Diskette Drives and Diskettes" in the *IBM Personal System/2 Hardware Maintenance Reference General Information* pamphlet.
- You must only install drives designed for this system. Use of drives not designed for this system could cause intermittent problems.

2.2 *Hard Disk and Diskette Drives*

The Model 95 comes with a Small Computer System Interface (SCSI) hard disk drive and SCSI adapter. Up to five SCSI devices can be installed inside the system. The default hard disk drive has the IML image preloaded in a protected partition. For information about the IML image, see "IML, POST, and BIOS" in topic 1.2.3.

For supported hard disk drives, see the parts section in the *Hardware Maintenance Service* pamphlet.

The Model 95 uses hard disk drives that automatically position and lock the read/write heads in nondata areas when the system is powered-off.

2.3 Terminators

Terminator requirements are:

- Diskette Drives: do not require terminators.
- Hard Disk Drives and other storage devices:
 - The last device in any SCSI chain must have the terminator installed. (Some devices may have more than one terminator.)
 - All other optional SCSI devices installed inside the system unit must have the terminators removed.
- SCSI Adapter: Terminator requirements for the SCSI adapter vary depending on the configuration of the system.

The location and appearance of the terminators may vary from drive to drive. An identification label or tag (usually "T-RES") is attached to each terminator for easy identification.

Note: For additional information on this subject, see "SCSI Devices" in the "Options and Adapters" section, of the Hardware Maintenance Reference manual.

3.0 *Operating Requirements*

This section describes the operations that occur from the time the system is powered-on until the minimum operating requirements have been met.

Subtopics

3.1 Power Supply

3.1 Power Supply

The power supply can be manually switched to support either the 100-125 Vac range or 200-240 Vac range. The ac input is converted to dc outputs that supply the system with proper operating voltages.

When the system is powered-off for 8 seconds or more and then powered-on, the power supply generates a 'power good' signal that resets system logic. The presence of the 'power good' signal turns on the green power-on light on the front of the system indicating that the power supply is functioning correctly.

4.0 Reference Diskette

There are two types of Model 95 Reference Diskettes. The type of processor board installed in the system determines which Reference Diskette is required.

Note: For more information, see "Processor Board and Reference Diskette Matrix" in the *Hardware Maintenance Service* pamphlet.

Subtopics

- 4.1 Installing a New Version of the Reference Diskette
- 4.2 Making a Backup Copy of The System Partition
- 4.3 Diagnostic Programs and Information

4.1 Installing a New Version of the Reference Diskette

Note: When you install the new Reference Diskette onto the hard disk, it writes over all the files (including option files) in the system partition. After completing the installation process, you must recopy the option files.

There are two ways to recopy the option files:

- From a backup copy of the current system partition (the easiest way to recopy the option files)
- From the original option diskettes.

If you have a backup copy of the current system partition, continue with the next step. If you *do not* have a backup copy, go to "Making a Backup Copy of The System Partition" in topic 4.2 and then return here.

1. Insert the new version of the Reference Diskette into the default diskette drive and power-on the system.

Warning: Before continuing, you *must* have either a backup copy of the current system partition or all the option diskettes so you can recopy the option files.

2. Go to the Main Menu of the Reference Diskette and select **Backup/Restore system programs**, then select **Restore the System Partition** and follow the instructions on the screen. This transfers all files, programs and the IML image from the new Reference Diskette onto the system partition.
3. When the Main Menu appears again, remove the Reference Diskette from the drive and power-off the system.
4. Wait five seconds and power-on the system.
5. When the POST finishes, press Ctrl+Alt+Del. When the cursor moves to the top-right corner of the screen, press Ctrl+Alt+Ins.
6. If you have a backup copy of the system partition, continue with step 7. If you *do not* have a backup copy of the system partition, but you have the option diskettes, go to step 8.
7. Select **Copy an option diskette** from the Main Menu. When the

Insert your option diskette

message appears, insert the backup copy of the system partition and follow the instructions on the screen. (The backup copy of the system partition is used to recopy the option files onto the system partition.)

Go to step 9.

8. When the Main Menu appears, select **Copy an option diskette** and follow the instructions on the screen. Repeat the procedure with each option diskette until you have copied all the option diskettes.
9. If your configuration is customized, continue with step 10. If not, go to step 11. (If you are not sure if the configuration is customized, continue with step 10.)

Warning: Do not run Automatic Configuration because the customized configuration will be overwritten.

10. Go to the Main Menu and select **Set configuration**. Then select **Set and view SCSI device configuration**. Press F3 to restore the customized configuration onto the system partition and exit from the program.
11. You are finished with the updating process. Make a new backup copy of the system partition. (For information on making a backup copy, see "Making a Backup Copy of The System Partition" in topic 4.2.)

4.2 Making a Backup Copy of The System Partition

Note: You will need a blank 2.0MB diskette (or the old backup copy of the system partition).

1. Power-on the system.
2. When the POST finishes, press Ctrl+Alt+Del. When the cursor moves to the top-right corner of the screen, press Ctrl+Alt+Ins.
3. When the Main Menu appears, select **Backup/Restore system programs**. Then select **Backup the System Partition**.
4. Insert a blank 2.0MB diskette into the default diskette drive and follow the instructions on the screen.

Note: If you receive a message indicating that the diskette is full, it means that the option files combined with the system programs on the system partition will not fit on a single 2.0MB diskette. In this case, you will not be able to make a backup copy of the system partition. Use the new Reference Diskette and the original option diskettes as a backup of these files.

5. When the copy is complete, remove the diskette from the drive and label the diskette "Backup Copy - System Partition."

4.3 Diagnostic Programs and Information

See the *IBM Personal System/2 Micro Channel Diagnostics* pamphlet for information on the following:

- System Programs
- Selectable Startup Function
- POST
- Advanced Diagnostic Programs
 - Presence Test
 - Installed Devices List
 - System Checkout
 - Error Log
 - Formatting.

5.0 Specifications

Size

- Depth: 508 mm (20.0 in)
- Height: 501 mm (19.75 in)
- Width: 203 mm (8.0 in).

Weight

- Minimum configuration: 22 kg (50 lb)
- Maximum configuration: 30 kg (67 lb).

Environment

- Temperature
 - Power-On: 10° to 32° C (50° to 95° F)
 - Power-Off: 10° to 43° C (50° to 110 ° F).
- Humidity
 - System On: 8% to 80%
 - System Off: 8% to 80%.
- Maximum altitude: 2134 m (7000 ft).

Heat Output

1245 British Thermal Units (BTUs) per hour (365.1 watts).

Electrical

- Input voltage (sinewave input is required)
 - Low Range:
 - Minimum: 90 V ac.
 - Maximum: 137 V ac.
 - High Range:
 - Minimum: 180 V ac.
 - Maximum: 265 V ac.
- Input kilovolt-amperes (kVA)
 - Minimum Configuration (as shipped from IBM): Approximately 0.18 kVA
 - Maximum Configuration: Approximately 0.78 kVA.

6.0 Special Tools

The following special tools are required to service the Model 95.

Volt-Ohm Meter

A meter similar to the Triplet Model 310. (1)

Wrap Plug

The Tri-Connector Wrap Plug (IBM part 72X8546) is used during advanced diagnostic tests of the parallel ports and the serial ports.

PICTURE 3

(1) Manufactured by Triplet Corporation, Bluffton, Ohio 45817,
U.S.A.

7.0 Removals and Replacements

The recommended service position of the Model 95 is upright. If necessary, you may place the system on its left side for servicing.

CAUTION:

The system unit with options may weigh as much as 30 kilograms (67 pounds). Be careful when moving or changing the position of the unit. Do not attempt to lift any object that you think is too heavy for you.

The arrows in the removal and replacement procedures show the direction to remove a field replaceable unit (FRU), or the direction to turn a screw, or to press a tab to release the FRU. The arrows are marked in numeric order to show the correct sequence of removal.

When other FRUs must be removed to remove the failing FRU, they will be listed at the top of the page. Go to the removal procedure for each FRU listed, remove it, then continue with the failing FRU removal.

To replace a FRU, reverse the removal procedure and follow any notes that pertain to replacement. See "Locations" for internal cable connection and arrangement information.

CAUTION:

Before removing any (FRU), power-off the system, unplug all power cords from electrical outlets, and disconnect any interconnecting cables.

Warning: The system board, adapters, memory modules and the math coprocessor can be damaged by electrostatic discharge. Use an electrostatic discharge (ESD) strap to establish personal grounding. If you don't have an ESD strap, establish personal grounding by touching a ground point with one hand before touching the static sensitive FRUs.

Subtopics

- 7.1 1005 Cover and Front Bezel
- 7.2 1010 Cover Lock
- 7.3 1015 Drive Retainer and Bezels
- 7.4 1020 Information Panel Assembly
- 7.5 1025 Diskette Drive
- 7.6 1030 Hard Disk Drive
- 7.7 1035 Adapters and Adapter Guide
- 7.8 1040 487SX Processor (extended math capability)
- 7.9 1045 Power Supply
- 7.10 1050 Memory Module Kit
- 7.11 1055 Battery
- 7.12 1060 System Board
- 7.13 1065 Adapter Retainer and Ground Assembly
- 7.14 1070 Rear Bezel
- 7.15 1075 Drive Support Structure
- 7.16 1080 Access Cover Fan
- 7.17 1085 Access Cover Fan Cable
- 7.18 1090 Option Hardware Trays
- 7.19 1095 Pedestal

7.1 1005 Cover and Front Bezel

PICTURE 4

7.2 1010 Cover Lock

- Cover and Front Bezel (1005)

PICTURE 5

7.3 1015 Drive Retainer and Bezels

- Cover and Front Bezel (1005)

PICTURE 6

7.4 1020 Information Panel Assembly

- Cover and Front Bezel (1005)
- Drive Retainer and Bezels (1020)
- Disconnect any cables necessary for removal.

PICTURE 7

7.5 1025 Diskette Drive

- Cover and Front Bezel (1005)
- Drive Retainer and Bezels (1015)
- Disconnect any cables necessary for removal.

Notes:

1. You must only install drives designed for this system. Use of drives not designed for this system could cause intermittent problems.
2. See "Internal Cables," page 8.4, for cable connections.

PICTURE 8

7.6 1030 Hard Disk Drive

Warning: Improper shipping and handling can result in permanent loss of all data and formatting on the hard disk drive. Have the user back up all information from the hard disk drive.

- Cover and Front Bezel (1005)
- Drive Retainer and Bezels (1015)
- Disconnect any cables necessary for removal.

Notes:

1. The last drive in the chain requires a terminator.
2. See "Internal Cables," on page 8.4 for cable information.
3. Load the IML image onto the replacement default drive. For more information, see "IML, POST, and BIOS" in topic 1.2.3.

PICTURE 9

7.7 1035 Adapters and Adapter Guide

Note: When replacing the processor board, be sure to push the levers in toward the expansion slot until they lock into place.

- Cover and Front Bezel (1005)
- Disconnect any cables necessary for removal

Note: Before replacing an adapter or processor board, note the slot location. Install the replacement FRU into the same slot.

Stored configuration information depends on the location of the adapter. If you must install the replacement adapter in a different location, run the set configuration program from the hard disk drive to reset the system-configuration information.

PICTURE 10

7.8 1040 487SX Processor (extended math capability)

- Cover and Front Bezel (1005)
- Adapters and Adapter Guide (1035)
- Disconnect any cables necessary for removal

Carefully insert the tip of a screwdriver between the processor and the connector edge and *gently* twist the screwdriver (around all edges) until the processor raises up.

When you reinstall the processor, align the beveled corner 1 with the beveled corner marked on the board.

PICTURE 11

On the 20-MHz board (left), the jumper 2 must be in positions 1 and 2 if a 487SX processor is installed.

Note: A slight gap between the processor and the connector is normal.

7.9 1045 Power Supply

- Cover and Front Bezel (1005)
- Disconnect any cables necessary for removal.

PICTURE 12

7.10 1050 Memory Module Kit

- Cover and Front Bezel (1005)
- Power Supply (1045) (Steps 2 and 3 only)

Notes:

1. If memory is added or removed, run the set configuration program from the hard disk drive to reset the system-configuration information.
2. If memory is replaced because it failed, the advanced diagnostic memory test must be run or the system will not recognize the replacement memory.

PICTURE 13

7.11 1055 Battery

- Cover and Front Bezel (1005)
- Power Supply (1045)

CAUTION:

The lithium battery presents a fire, explosion, or severe burn risk. Do not recharge it, disassemble it, heat it above 100°C (212°F), incinerate it, or expose its cell contents to water. Dispose of the battery as required by local ordinances or regulations. When replacing the battery, use only Part No. 33F8354. Use of another battery could result in ignition or explosion of the battery. Replacement batteries can be ordered from IBM or IBM Authorized Dealers.

Warning: The battery is located on the system board. Be careful when removing or replacing the battery. If the battery clip is broken the system board must be replaced.

Note: If the battery is removed, run the set configuration program from the hard disk drive to reset the system-configuration information.

PICTURE 14

7.12 1060 System Board

- Cover and Front Bezel (1005)
- Adapters and Adapter Guide (1035)
- Power Supply (1045)
- Hard Disk Drives (1030) (if necessary)
- Disconnect any cables necessary for removal.

Note: When a new system board is installed, run the restore configuration program from the hard disk drive to restore time, date, and any unique configuration data. Reset the start-up sequence.

PICTURE 15

7.13 1065 Adapter Retainer and Ground Assembly

- Cover and Front Bezel (1005)
- Adapters and Adapter Guide (1035)
- Power Supply (1045)
- System Board (1060)
- Disconnect any cables necessary for removal.

Note: Loosen and remove the expansion slot covers before removing the rear bezel.

PICTURE 16

7.14 1070 Rear Bezel

- Cover and Front Bezel (1005)
- Adapters (1035)
- Power Supply (1045)
- System Board (1060)
- Disconnect any cables necessary for removal.

Note: Loosen and remove the expansion slot covers before removing the rear bezel.

PICTURE 17

7.15 1075 Drive Support Structure

Warning: When removing or replacing the drive support structure, be careful not to bend the ground spring. A damaged ground spring can result in intermittent noise problems.

- Cover and Front Bezel (1005)
- Drive Retainer and Bezels (1015)
- Diskette Drives (1025)
- Hard Disk Drives (1030)
- Power Supply (1045)
- System Board (1060)
- Disconnect any cables necessary for removal.

PICTURE 18

7.16 1080 Access Cover Fan

The access cover fan is located on the inside of the system access cover.

- Cover and Front Bezel (1005)

PICTURE 19

7.17 1085 Access Cover Fan Cable

- Cover and Front Bezel (1005)
- Power Supply (1045)
- Disconnect the fan cable from connector J28 on the system board.

PICTURE 20

7.18 1090 Option Hardware Trays

- Cover and Front Bezel (1005)
- Drive Retainer and Bezels (1015)

The option hardware trays contain cables and rails needed for installation of option devices. The trays also help to direct air flow when no options are installed in the D bays. The trays should remain in the D bays until options are installed.

Note: The location and quantity of the trays will vary depending on the configuration of the system.

PICTURE 21

7.19 1095 Pedestal

Note: Pull out on the tabs just far enough to release the pedestal.

PICTURE 22

8.0 Locations

Subtopics

- 8.1 Front View
- 8.2 Rear View
- 8.3 Interior View
- 8.4 Internal Cables
- 8.5 System Board
- 8.6 Processor Board

8.1 Front View

- 1 Power switch
- 2 Power-good light
- 3 Information panel
- 4 Serial number
- 5 Diskette drive (Bay A)
- 6 Diskette drive in-use light
- 7 Diskette-eject button
- 8 Bay B
- 9 Bay E
- 10 Bay D
- 11 Bay D1
- 12 Cover lock.

PICTURE 23

8.2 Rear View

- 1 Expansion slots
- 2 Serial port
- 3 Parallel port
- 4 Pointing-device connector
- 5 Keyboard connector
- 6 Power-cord connector
- 7 Serial number
- 8 Voltage-select switch.

PICTURE 24

8.3 Interior View

- 1 SCSI adapter
- 2 Adapter retainer and ground assembly
- 3 Processor board
- 4 Access Cover Fan Cable
- 5 System board
- 6 Power supply
- 7 Option device bays
- 8 Hard disk drive
- 9 Drive retainer
- 10 Diskette drive.

PICTURE 25

8.4 Internal Cables

This diagram shows the arrangement of the cables that connect the various devices.

- 1 Information-panel cable
- 2 External-device cable connector
- 3 System board
- 4 Access Cover Fan
- 5 Power supply
- 6 Device power cables
- 7 Signal cable
- 8 Diskette-drive cable.

PICTURE 26

8.5 System Board

- 1 32-bit expansion slots (video extensions J9, J11)
- 2 Processor-board slot
- 3 Serial port
- 4 Parallel port
- 5 J28 connector (access cover fan)
- 6 Pointing-device connector
- 7 Keyboard connector
- 8 Memory-module connectors
- 9 Power-supply connector
- 10 J16 connector (power-on password)
- 11 Battery connector
- 12 Diskette-drive cable connector
- 13 Operator-panel cable connector.

PICTURE 27

8.6 Processor Board

Use the following information to locate the connectors and jumpers on the various processor boards, and to identify the purpose of those connectors and jumpers.

Note: The locations may vary slightly.

1 Processor connector (all boards).

2 Option Processor connector (25-MHz boards without Cache) is for a 487SX processor with math capability.

3 Jumper (20-MHz boards). If a 487SX processor (labeled 487SX) is installed, the jumper must be in positions 1 and 2. If a 487SX processor is *not* installed, the jumper must be in positions 2 and 3.

Note: On the 20-MHz board, if a 487SX processor is installed, it is in connector 1.

4 Cache connector (all boards that support Cache).

PICTURE 28

9.0 Grounds

- 1 Screws
- 2 Expansion slot screws
- 3 Chassis ground
- 4 Primary ground
- 5 Power-cord connector.

PICTURE 29

Notes: