



CREATOR

31029




LEGO.com/creator




2x

1



2




2x

2



2x


3





4x

4



2x

5





1x



1x


6




1x

7





8





1x



2x

9





4x




2x

10



2x



4x




2x

11



2x






1x



1x

12

1



2





2x



2x

13



2x





1x



1x

14



10



2x

15





2x

16



2x

1x

17





2x



1x

18



12



1x

19





1x

1



1x

2



3

1x





4

1x




1x







2x

5



2x


6





2x

7



16




1x



1x

8






1x




1x

9



2x

10





2x



1x

20





3x




3x




3x

21



1x

1





1x

2




1x



1x

3





1x



2x

4



1x

5





1x



1x

6




1x

7





22





2x

23





2x



2x

24



1x

25






1x



1x

26





1x



1x



1x



1x



2x

27


1



2



3



4



5

