



40123



1



2




3




4





2x


1





1x

2



4




1x





2x

3






4



5





1x





1x



2x

6



6





1x





1x

7






8



9






1x



4x

10





2x





1x

11






12



13





1x



2x




2x



1x

14



1x




1x




1x

15







2x



1x

16





1x




1x



1x

17





1x



2x

18



1x



1x



1x

19





1x



1x

20



1x



1x

21





2x



1x

22



2x

23





1x



1x



1x



1x

24

1



2





4x

25





2x



2x

26



18



4x


27






1x

1



2x

2




1x



2x

3



2x



2x

4





1x



2x

5



2x

6



20

28





1x



1x



2x

29



1x



1x




1x



2x

30





1x



1x



1x

31



1



2





1x




1x



1x

32



1



2





1x




1x



1x

33




1




2





34





1x

1



4x



1x

2





1x



1x

3



1x

4







2x



2x

5



1x



1x



1x

6





1x



1x



1x

7



2x



1x

8

1



2







Customer Service

Kundenservice

Service Consommateurs

Servicio Al Consumidor

LEGO.com/service or dial



: 00800 5346 5555

: 1-800-422-5346



LEGO and the LEGO logo are trademarks of the/son des marques de commerce du/son marcas registradas de LEGO Group.
©2015 The LEGO Group. 6123836 / 6123837