




Disney

43177





6310705 **WARNING: CHOKING HAZARD.**
Small parts. Not for children under 3 years.


1




2



3





4



Disney PRINCESS





LEGO.com/service

LEGO.com/disney

⚠ AVERTISSEMENT : RISQUE D'ÉTOUFFEMENT.
 Contient des petites pièces. Ne convient pas aux enfants de moins de 3 ans.

⚠ ADVERTENCIA: PELIGRO DE ASFIXIA.
 No recomendado para niños menores de 3 años. Contiene piezas pequeñas.