



CITY




60182



 LEGO.com/city



WARNING: CHOKING HAZARD.
Small parts. Not for children under 3 years.



+






38



AVERTISSEMENT : RISQUE D'ÉTOUFFEMENT.
Contient des petites pièces. Ne convient pas aux enfants de moins de 3 ans.




ADVERTENCIA: PELIGRO DE ASFIXIA.
No recomendado para niños menores de 3 años. Contiene piezas pequeñas.







1x

39





40






1x





2x


41

1




2






42






43








44







45





46





1x



2x



1x



1x

47



1




2





3










48







49









50







51





52







53





1x


54





2x

55







1x

56

1



2






1x


57

1





2






58






2x


59






1x


60




1x

61






62





2x

63




1x



1x


64







2x

65






66



67






1x



1x


68







1x

69



2x

70






2x



1x


71





2x

72



1x




1x

73



1




2



74




75





2x


76







1x

77





78





4x




2x

79




2x







1x


80








81








82






83





84






1x



2x

85







1x




2x


86







87









88





89




90




91






92





93





1x


94





1x

95







1x



1x

96







2x



1x

97





1x




1x




1x


1




2





98







99



100







2x
4259903



1x
614123



1x
6123860



3x
302323



3x
306923



1x
243223



1x
9566



2x
4514553




2x
362323



1x
371023



1x
6102759



1x
346023



1x
447723



1x
6112620



1x
4651443



1x
4584727



1x
389924



1x
302323



1x
371024



1x
6152450



1x
6152679



1x
6210620



1x
6115306



2x
614126



2x
307026



1x
4653226



2x
4121715



1x
4106552



2x
6047276



1x
4140588



4x
6029208



2x
4183043



2x
6061032



3x
4565323



1x
4142822



2x
4531412



1x
371026



4x
4619323



1x
6081988



1x
366626




1x
395826



1x
6001494



1x
4569058




2x
371028



1x
4243821



1x
346028



1x
303428



1x
6182225



1x
3006840



1x
4650498



2x
4244362



1x
4219773



4x
4646864



2x
3000841



2x
4201019



1x
6047056



2x
4163696



1x
4597999



1x
4623481




2x
6102359



1x
6040301



2x
4638658



Customer Service
Kundenservice
Service Consommateurs
Servicio Al Consumidor
LEGO.com/service or dial



: 00800 5346 5555
 : 1-800-422-5346



60141



60140



60139



60138



60137



LEGO CITY



60167



60166



60165



60160



60161



60159