

Assemble Manual

PART ONE - ASSEMBLE THE WHEELS















PART	QTY	NOTE
OREAR/FRONT WHEEL	2*2	IN CARTON
2NUT	3/WHEEL	ATTACHED
®BOLT	3/WHEEL	ATTACHED

- 1, The @nuts and @bolts are fixed in the flange.
- 2, Loose the 2nut and 3bolt.
- 3, Slide (Dwheel onto axles.
- 4, Secure (1) wheel with nuts and bolts.

Attention

- 1, The valve of wheel should be positioned forth.
- 2, The pattern of front/rear tire should be adjusted as arrow direction (as picture 5&6).


PART TWO - ASSEMBLE BATTERY



Attention


- 1, Please notice the ① sign of Positive lead and Negative lead.
- 2, To connect the red line to Positive lead and v.v.

PART THREE - ASSEMBLE THE PROTECTION SHELF



- 1, The uninstalled Oprotection shelf.
- 2, Loose the 2nut and 3bolt upside.
- 3, Loose the 2nut and 3bolt downside
- 4, Fix the ①protection shelf onto frame.
- 5, Secure () protection shelf with (2) nut and (3) bolt

PART FOUR - ASSEMBLE THE HANDLE BAR



PART	QTY	NOTE	
①HANDLE BAR	1	IN CARTON	
2BOLT	4	ATTACHED	
34BRACKED	2	ATTACHED	

- 1, Every item is dismantled.
- 2, Place the ③bracket-downside.
- 3, Put up the Dhandle bar and place the pattern part in the middle.
- 4, Secure the ①handle bar with the ④bracket-upside.
- 5, Use the L-shape tool to fasten the ②bolts.