




40122








1




2





2x

1




4



1x

2




1x



2x

3






2x



2x

# 4



6




1x



2x

# 5






4x



2x

# 6



1x





1x




1x

# 7






8



8



9







6x

10




2x



2x


11






# 12

1



2



3



4



5





2x

# 13





2x



2x

# 14





1x



1x




1x



1x

# 15



1x



2x

# 16





4x




2x




2x

# 17

1



2



2x





2x



2x




1x



# 18



2x



# 19











20





1x

# 21




2x



2x

# 22





1x

23



20



2x



2x

24





2x



2x

# 25



2x



2x

# 26



2x



2x




1x



1x

1



1x

2





1x



1x



1x

3



2x

4






1x



1x

5




2x



2x

6







2x

7




1x



1x

8







**Customer Service**

**Kundenservice**

**Service Consommateurs**

**Servicio Al Consumidor**

**LEGO.com/service or dial**



**: 00800 5346 5555**

**: 1-800-422-5346**



LEGO and the LEGO logo are trademarks of the/son des marques de commerce du/son marcas registradas de LEGO Group.  
©2015 The LEGO Group. 6123834 / 6123835