



CITY

60202




 [LEGO.com/city](https://www.lego.com/city)



WARNING: CHOKING HAZARD.
Small parts. Not for children under 3 years.











AVERTISSEMENT :
RISQUE D'ÉTOUFFEMENT.
Contient des petites pièces.
Ne convient pas aux enfants
de moins de 3 ans.





ADVERTENCIA:
PELIGRO DE ASFIXIA.
No recomendado para
niños menores de 3 años.
Contiene piezas pequeñas.












1



2





2x

3



8



1x

4



1x

5





1x

6



1x






1x


7













1






2





2x


3






2x

4



2x


5





2x


6






2x

7



2x


8







2x

9






10




11




12



13






1



2



3




1



2



3











CITY



60170



60171



60176



60172



60173



60174



 1x 6209910	 1x 9342	 1x 6105708	 1x 6100222	 1x 6153140	 1x 6015891	 1x 4596914	 1x 6170765	 2x 6238677
 1x 6139552	 2x 6105976	 1x 6223882	 1x 6231933	 1x 6153141	 1x 306226	 1x 9339	 2x 4565321	 1x 4567332
 1x 4549059	 2x 306821	 1x 6223923	 1x 6231940	 1x 6225209	 2x 6186675	 1x 302326	 2x 4243821	 2x 6231925
 1x 6093053	 2x 302021	 1x 6226749	 1x 6231949	 1x 6225209	 1x 614126	 2x 6064174	 1x 6182261	 2x 6192246
 2x 6047220	 1x 4586188	 1x 6224063	 1x 6231969	 1x 6210620	 1x 6134617	 2x 452226	 1x 4614107	 2x 6192246
 2x 302201	 1x 9341	 1x 4652361	 1x 6231969	 1x 6224075	 1x 6157554	 1x 452226	 1x 6194006	 1x 6228496
 1x 4107623	 1x 9341	 1x 6224208	 1x 6153512	 1x 6219628	 1x 474026	 1x 6223896	 1x 4650498	 1x 6228496
 1x 6024495	 1x 6204394	 1x 6225238	 1x 6224041	 1x 6219628	 1x 4106552	 1x 4650498	 1x 6245250	 1x 4267425
 2x 6233807	 1x 6103171	 1x 6224106	 1x 6223880	 1x 6224126	 1x 452826	 3x 6081988	 1x 6245250	 1x 4267425
 1x 389921	 1x 6116616	 1x 6153341	 1x 6223880	 1x 6224126	 1x 452826	 3x 6081988	 1x 6245250	 1x 4267425

1x
6132767

1x
4524098

1x
6209990

1x
6233539

1x
4162916

1x
6207255

1x
6240227

3x
4211183

1x
4529242

2x
6062574

1x
6227107

1x
6182435

1x
6194410

1x
4598713

3x
4211166

1x
6069984

1x
6035547

1x
6121728

1x
6167644

1x
6226742

1x
6226744

1x
4579690

4x
4211525

1x
6168647

4x
6170569

1x
4550170

1x
6234563

2x
4590443

1x
6076806

2x
4515374

3x
4211098

2x
4211095

1x
4222693

4x
6039479

1x
4211075

2x
4211135

1x
4211054

1x
6000853

1x
6092833

1x
6065515

1x
4581313

1x
4529672

1x
6163633

1x
6218268

1x
6162292


1x
4611885

2x
6225073


1x
6063520

1x
6038640


1x
6232083



1x
6228814



1x
4166619



1x
6099480



1x
6232185

Customer Service

Kundenservice

Service Consommateurs

Servicio Al Consumidor

LEGO.com/service or dial



: 00800 5346 5555

: 1-800-422-5346





LEGO CITY



LEGO and the LEGO logo are trademarks of the/son des marques de commerce de/son marcas registradas de LEGO Group. ©2018 The LEGO Group. 6245949

60192

60193

60194

60195