





# CREATOR™




31086




3 in 1  
3 en 1  
3 az 1-ben  
Trīs vienā  
3 合 1





**1**







2



3






1x




2x



4










5








6






7







8







9





2x

10



10





1x




2x

# 11







12








13







15





2x




1x




1x


# 16






17





18






2x



2x

# 19





2x




1x



1x

# 20








2x



2x


# 21







2x

22




2x






23







2x

24



2x







2x






2x

# 25







26





3x

27






1x



1x

# 28



1x

# 29










1x


30



1x

31









2x



2x




2x




2x

33


1




2



3



2x






4x



4x

# 34



4x




1x



1x

35




34



2x


36





1x

37



36





# CREATOR™

3 IN 1



31086



31087



31088



31089



31090



31091



LEGO.com/creator



# CREATOR™

7 [LEGO.com/creator](https://www.lego.com/creator)



31088



31090

1x  
4518400

2x  
6213880

2x  
6213881

2x  
4161326

2x  
4160857

2x  
403201

1x  
4667575

4x  
6023099

2x  
306801

6x  
242001

2x  
4612342

3x  
6170524

3x  
302101

4x  
243101

3x  
302001

1x  
6178921

3x  
4206482

1x  
6145661

2x  
6252042

4x  
6124858

2x  
6252046

2x  
6171717

1x  
4539114

4x  
6083977

8x  
6092597

2x  
6214309

1x  
4541544

2x  
4539060

1x  
6042953

1x  
6250102

2x  
6250104

2x  
4618986

4x  
6167741

4x  
4211399

2x  
4558953

1x  
6057616

6x  
6043656

4x  
6028813

2x  
4211414

2x  
4211440

1x  
4258273

1x  
4258275

2x  
4654577

1x  
4507056

1x  
4209006

1x  
4208988

2x  
4211397

3x  
4211351

4x  
4211353

2x  
4211636

1x  
4211406

3x  
6005463

2x  
4210848

2x  
6158469

6x  
4587212

3x  
4211063

2x  
6215212

4x  
6039479

2x  
4211066

4x  
4210660

1x  
6015356

1x  
6083620

1x  
4549886

3x  
4211002

1x  
4625146

4



Customer Service

Kundenservice

Service Consommateurs

Servicio Al Consumidor

LEGO.com/service or dial



: 00800 5346 5555

: 1-800-422-5346





# CREATOR™

# 3 IN 1



LEGO and the LEGO logo are trademarks of the/lesont  
des marques de commerce d'ul/son marcas registradas  
de LEGO Group. ©2019 The LEGO Group.  
6263524/6263527



31084