




Friends



3189






+




2x

1






2







4x

3






4






5








2x

6








7









8





9





10





2x

11






2x

12





13






1x




1x


14






15





16





17





6x

18





4x

19







4x


20







21





22






23






4x


24





2x

25





2x



4x

26







2x



2x

27






28






1x


29







30







31




32







33



2



2x





34

1






2





1x

35





1x



1x

36

1



2



3



4







5x
300501



2x
245301



1x
4186952



6x
300401



1x
611201



4x
4117061



9x
302301



2x
346001



1x
379401



4x
306901



Customer Service

Kundenservice

Service Consommateurs

Servicio Al Consumidor

LEGO.com/service or dial



00800 5346 5555 :



1-800-422-5346 :



1x
4282737



2x
4651885



1x
4530590



6x
4541808



6x
395701



1x
4622821



2x
4611700



1x
4615649



2x
4558168

2x
4624988



8x
4129996



2x
4568718



2x
4512688



4x
4113915



26x
4109995



26x
4113916



6x
4112982



1x
4615599



16x
4121972



2x
4503204



4x
4624985



4x
4563683



13x
287724



2x
374724



6x
302324



2x
4565386



3x
302124



2x
4599537



2x
366624



1x
4256320



2x
6012442

1x
249626



1x
4528331



1x
7517925



1x
6016718



2x
4599734



8x
379428



5x
374128



2x
4114348



1x
4157270



1x
4243784



1x
4626884

1x
4624987



1x
4615606



1x
6017997



1x
4106915



4x
302321



2x
4550172



1x
6003001



2x
371023



4x
306923



1x
4140586



4x
4514398



1x
403223



4x
4525858



13x
4164021



1x
4622815



2x
4520810



4x
4187743



2x
4179833



5x
4651918



4x
4626883



2x
4624986



1x
4546448



3x
4618668



1x
4622669



7x
4580010



1x
4615728



4x
4599687



1x
4599732



4x
4599538



4x
4517995



4x
4618671



2x
4580007



1x
6016662



1x
6017021



1x
6017024



1x
4612390



2x
4263776



1x
4618542



4x
4211150



1x
4216695



8x
4211190



6x
4221590



2x
4271874



1x
4533101



1x
4624905



1x
6016671



4x
4244627



6x
4211413



2x
4211356



1x
4611978



8x
4567448



1x
4618666



1x
4618603



1x
4216375



2x
4243677



2x
4618670



1x
4625278



1x
4621315



1x
6016664




8x
4539099



2x
4585518



1x
4541060



2x
4618669



2x
4619599



1x
4107050



2x
4119479



3x
4611777



2x
4119478



1x
4654448



4x
4249040



1x
4163917

Heartlake City



 Friends



3183



3063



3186



3931



3930



3061



3315



3187



3188



3942



3065



3184



3938



3939



3935



3932



3937



3933



3936



3934



3189



3185



www.LEGOclub.com/Nina



club™

FREE*! GRATIS! GRATUIT!

*Paid subscription in Australia and New Zealand.
*Abonnement payant en Australie et Nouvelle-Zélande.

© 2012 The LEGO Group.



Friends



LEGOFriends.com



LEGO and the LEGO logo are trademarks of the/
sont des marques de commerce de/son marcas
registradas de LEGO Group. ©2012 The LEGO Group.
6045330 / 6045331