




# CREATOR

31042



[LEGO.com/creator](http://LEGO.com/creator)




1x



1x

1




2



2x

2





1x




1x




1x

3



2x

4






1x




1x

5




4



1x

6








2x




2x

7



1x

8







1x



1x

9




2x



1x

10






1x




1x

11



1x

12






1x



1x




1x



1x

# 13







1x



2x





1x



1x

# 14




1x



1x

# 15





1x




1x



1x

# 16




1x




3x

# 17





18





1x





1x



1x


# 19





1x

20



1x



1x

21





1x

22



1x

23



1x



1x

24






1x




1x

# 25



1x


# 26





1x

27



1x




1x

28






29




30





1x

31



1x



1x

32





1x

# 33



1x

# 34



1x



1x

# 35






1x




1x

36



1x


37





1x

38




1x




1x


39



40



41





**Customer Service**

**Kundenservice**

**Service Consommateurs**

**Servicio Al Consumidor**

**LEGO.com/service or dial**



**: 00800 5346 5555**

**: 1-800-422-5346**