


LEGO

TECHNIC


42028





1




2







1






2







3







4







5









6






7







8







9



4x

2x



10





2x






11






12






13










2x

14




15







1






2








3




4





5






4



5







2x




2x

6





2x

7





16






17



1:1







4x




4x

18



2x



2x




4x



2x

19







4x




4x


20







21






22





23





4x



8x



4x






1

2



4x


24






25






26





2x

27



22




1x



21





1x

28







1







2








3








4







5






6









1





2



3




4





2x

5




1x




1x

6



2x

7



1x

55




1x




1x

8



55




55

1:1





9



11

10






1x



1x


12



1x

55

13




55

1:1




1x

14



2x


15






1x

16




2x


17



29





30






31








1





2







3




4






2x

5




2x

6



1:1



1x





1x




1x

7








8



9




10






2x

11




2x

12



2x


13






2x

14




4x


15




32



33






34





35







1




2




3



4





4x






5



36






37



Customer Service
Kundenservice
Service Consommateurs
Servicio Al Consumidor
LEGO.com/service or dial

00800 5346 5555 : 
 1-800-422-5346 : 