



CREATOR

31062



LEGO.com/creator



WARNING: CHOKING HAZARD.
Toy contains small parts and a small ball.
Not for children under 3 years.



AVERTISSEMENT : RISQUE D'ÉTOUFFEMENT.

Le jouet contient des petites pièces ainsi qu'une petite boule.
Il ne convient pas aux enfants de moins de 3 ans.




ADVERTENCIA: PELIGRO DE ASFIXIA.

Juguete que contiene partes pequeñas y una pelota pequeña.
No recomendado para niños menores de 3 años.



1x

1





2



2x


2






2x

3



2x


4





1x

5




4





2x

6







7





8





9






2x




2x

10



2x


11






2x

12



1x

13






2x

14



2x





1x





2x

15







16






17






18






2



3




4







19






2



3




4






1x

20



2x


21







4x

22



2x



23





2x

24



2x





2x



2x


25






2x

26



1x


27





2x

28





2x



2x


29







1x

30



1x


31





2x

32





1x





1x

33






34




4





5



6



35





1x
6121787



1x
241201



1x
6013484



1x
6089574



5x
4227155



2x
4142865



3x
4239601



2x
4504382



40x
6047885



2x
4548180



3x
403226



2x
4121715



2x
6047276



2x
4233487



1x
306926



1x
6117973



2x
6097072



2x
4225201



1x
4213374



1x
302226



2x
6053077



1x
4541455



2x
6019217



1x
4504187



1x
4260488



1x
4613153



2x
371026



1x
4619763



1x
6052851



2x
389426



2x
4215618



2x
4646860



2x
3005749



3x
6076751



2x
4222960



1x
6135494



2x
6159763



2x
4211525



10x
4211399



2x
4211375



1x
4211732



1x
4211735



2x
4640536



2x
6015344



2x
6043656



4x
6144138



2x
4651063



2x
4556157



2x
6011817



4x
4667578



2x
4211632



2x
6034676

2x
4211429



1x
4234251



2x
6132872



1x
4622803



1x
4211438



1x
4160560



2x
4278274



2x
4161674



2x
4210763



6x
4211063



2x
6092572



2x
4211135



4x
4210635



2x
4211060



1x
4225973



1x
4497253



1x
4227395



2x
4619760



2x
4227398



1x
6065816



1x
4499858



2x
4619520



2x
4619652



2x
4649741



4x
4655246



1x
6060857



1x
6173655



2x
6035598



1x
6146866



2x
6177664



1x
6097093



1x
4624705



2x
6052823



1x
6015098



1x
4655256


Customer Service

Kundenservice

Service Consommateurs

Servicio Al Consumidor

LEGO.com/service or dial



: 00800 5346 5555

: 1-800-422-5346

31058

3 IN 1

4

LEGO and the LEGO logo are trademarks of the/son des
marques de commerce du/son marcas registradas de
LEGO Group. ©2017 The LEGO Group.

6188406

LEGO.com/creator