



40237




WARNING: CHOKING HAZARD.
Toy contains small parts and a small ball.
Not for children under 3 years.



LEGO.com






**AVERTISSEMENT :
RISQUE D'ÉTOUFFEMENT.**

Le jouet contient des petites
pièces ainsi qu'une petite boule.
Il ne convient pas aux enfants
de moins de 3 ans.




**ADVERTENCIA:
PELIGRO DE ASFIXIA.**


Juguete que contiene partes
pequeñas y una pelota pequeña.
No recomendado para niños
menores de 3 años.




1



4



2





1x

3





1x



1x


4






1x

1



6




2x

1x

2x

2






2x




2x


3




2x

4






5



8



6






1x



1x

7




1x



1x


8





2x

9





10





2x

10





11








2x

12








13







14






1x

1





2






3



4





2x



2x



2x



2x

5



1x





1x

6





7








1x


8








9







10







1





2







3





4







5





6






1x



1x

7




1x



1x


8






2x

9



2x


10





1x

11





28





1x

12






13



14







Customer Service

Kundenservice

Service Consommateurs

Servicio Al Consumidor

LEGO.com/service or dial



: 00800 5346 5555

: 1-800-422-5346

