



Disney  
PRINCESS

41069



[LEGO.com/disneyprincess](http://LEGO.com/disneyprincess)





**WARNING: CHOKING HAZARD.**

Toy contains small parts and a small ball.  
Not for children under 3 years.



2




1



2





1x

1




**AVERTISSEMENT :  
RISQUE D'ÉTOUFFEMENT.**

Le jouet contient des petites pièces ainsi qu'une petite boule. Il ne convient pas aux enfants de moins de 3 ans.



**ADVERTENCIA:  
PELIGRO DE ASFIXIA.**


Juguete que contiene partes pequeñas y una pelota pequeña. No recomendado para niños menores de 3 años.






1x


2



4



**3**






1x



1x

4




6



2x


5





2x

6




8





2x

7





1x



1x




1x



1x

8






1x



1x


9






1x


# 10



12




11





1x


# 12





1x

# 13






# 14

1



2





3





4







1x



1x

# 15








1x



1x


# 16





1x


1






2x

2



1x

3






2x



1x

4






2x



1x


5





1x



6







7






2x



1x


8





1x

9






1x



2x

# 10






1x



1x

# 11





1x



1x



1x

# 12

1



2







1x  
614301



1x  
393701



2x  
302301



4x  
235701



1x  
4612342



1x  
301001



2x  
4597131



1x  
365901



1x  
302001



3x  
4117070



2x  
6017003



1x  
4140562



1x  
4109995



1x  
6046922



1x  
4113917



1x  
4121972



1x  
6134395



2x  
4163917



4x  
6066124



1x  
6070495



3x  
4599535



2x  
6058337



1x  
6114993



1x  
4143404



2x  
6093750



1x  
6097098



3x  
4624184



1x  
6060731



2x  
4216479



1x  
6060801



2x  
6060795



2x  
4649749



3x  
4580010



1x  
6096589



1x  
4655695



1x  
6097516



1x  
4569316



2x  
4538126



1x  
6087082



1x  
6062386



2x  
4623598




1x  
6074906



1x  
4504850



1x  
6003008



1x  
6097036



**Customer Service**

**Kundenservice**

**Service Consommateurs**

**Servicio Al Consumidor**

**LEGO.com/service or dial**



**00800 5346 5555 :**



**1-800-422-5346 :**







41055



41063



41062



41061



41068



41066





[LEGO.com/disneyprincess](http://LEGO.com/disneyprincess)





Disney PRINCESS

Disney Whisker Haven  
FAVORITE DISNEY PRINCESS PETS



41141



41069



41140



41142



Disney Whisker Haven  
FAVORITE DISNEY PRINCESS PETS