



CITY

60113




LEGO.com/city





WARNING: CHOKING HAZARD.
Small parts. Not for children under 3 years.




 **AVERTISSEMENT :**
RISQUE D'ÉTOUFFEMENT.
Contient des petites pièces.
Ne convient pas aux enfants de
moins de 3 ans.

 **ADVERTENCIA:**
PELIGRO DE ASFIXIA.
No recomendado para niños
menores de 3 años.
Contiene piezas pequeñas.






1



1





2




3




4



1



2






2x



1x


3





6



4




5





2x

6




8




1x

7



2x



8





1x

9







1x





1x

10



1x


11







1x

12






13




14








1x

15






16




17






1x



18






1x

21







1x

22

1





2





1x

23






1x



2x

24




2x

25





26





2x



2x

27

1



2



2x







2x

28





29







2x

30






31




32





1x

33






2x




2x

34



4x


35







4x

36




37





1x

38



2x



2x

39





2x

40




41





1x

42




2x



2x


43







1x

44



1x


45






2x

46






47





48







CITY



60076



60074




60073



60072

LEGO.COM/CITY



Customer Service

Kundenservice

Service Consommateurs

Servicio Al Consumidor

LEGO.com/service or dial



: 00800 5346 5555

: 1-800-422-5346