



CITY

7939






+




1




2





3




4




5



6




7





2x


1




2



3




4




2x


8




9



10




11






2x


1




2




3




4



5




6




2x

12







1




2




3




4




5




6







7




8




9




10




11




12



13



15



LEGO

CITY



7241



7942



7239



7207



7208



CITY



3177



3178



3179



3180



3181



3182

FREE! GRATIS! GRATUIT!





club
MAGAZINE™

www.LEGOclub.com



00800 5346 5555*        

  **1-866-534-6258 • 1-877-518-5346**

US & Canada only

Canada seulement

* Freephone. Mobile charges may apply. * Numéro sans Frais. Des Frais peuvent s'appliquer avec les téléphones cellulaires. * Gebührenfrei, Kosten Für Anrufer aus Mobilfunknetzen können abweichen.
* Gratis telefoonnummer vanaf vaste lijn. * Det er ett gratis nummer, når du ringer fra Fasttelefon. * Det är gratis, när du ringer från en Fast telefon.



VISIT THE WORLD'S
BIGGEST LEGO® SHOP!

www.LEGOshop.com