

## **Quick Start Guide**

Smart Temperature and **Humidity Sensor** 



Scan QR code or visit

https://www.tp-link.com/support/


setup-video/#smart-sensors



# \*Images may differ from actual products

## Meet Your Temperature and Humidity Sensor

Measure the temperature and humidity of the environment and send you instant notifications when the environment changes. It is suitable for green houses, bedrooms, nursery, incubators, and wine cellars.



## Before You Start

A Tapo Hub is required. Make sure your Tapo Hub is successfully added via the Tapo app.



# 1 Power Up Your Sensor

Remove the battery insulation tab to power up your sensor. The LED should blink.

Note: If the LED is not blinking, use a pin to press the Reset button for 5 seconds to reset your sensor and enter pairing



# 2 Set Up Your Sensor

Open the Tapo app and tap the  $\oplus$  button. Select **Sensors** and then your model. Follow the app instructions to complete setup.



## 3 Test Your Sensor

Take your sensor to the preferred location.

#### Option

Single press the Reset button. Your hub should make a voice prompt.

### Option 2

Blow on the sensor detector. The temperature and humidity displayed on the Tapo app should



# 4 Place Your Sensor

(The installation height should not be higher than 2 meters/6.56 feet.)

### Option 1: Hang with the Lanyard





## 4 Place Your Sensor (The installation height should not be higher than 2 meters/6.56 feet.)

#### Option 2: Use Adhesive Magnets

a. Stick the included adhesive magnets to the back panel.





# b. Magnetically attach the sensor to metallic




Metallic Surface

surfaces.










- 1. Use a pin to press and remove the cover.
- 2. Replace the battery with a fresh cell (battery model: CR2450).

? How to replace the battery

3. Put the cover back.



# **A** WARNING

- INGESTION HAZARD: This product contains a button cell or coin
- **DEATH** or serious injury can occur if ingested.
- A swallowed button cell or coin battery can cause Internal Chemical Burns in as little as 2 hours.
- KEEP new and used batteries OUT OF REACH of CHILDREN
- Seek immediate medical attention if a battery is suspected to be swallowed or inserted inside any part of the body.
- If the battery compartment does not close securely, stop using the product and keep it away from children.



### Explanation of the symbol on the product

Warning! This product contains a button cell or coin battery. Avoid ingestion hazard. Death or serious injury can occur if ingested.

Avoid replacement of a battery with an incorrect type that can defeat

Avoid disposal of a battery into fire or a hot oven, or mechanically crushing or cutting of a battery, that can result in an explosion.

Do not leave a battery in an extremely high temperature surrounding environment that can result in an explosion or the leakage of flammable liquid or gas; Do not leave a battery subjected to extremely low air pressur that may result in an explosion or the leakage of flammable liquid or gas.

#### CAUTION!

Risk of explosion if the hattery is replaced by an incorrect type

a) Remove and immediately recycle or dispose of used batteries according to local regulations and keep away from children. Do NOT dispose of batteries in household trash or incinerate.

- b) Even used batteries may cause severe injury or death.
- c) Call a local poison control center for treatment information.
- d) This product includes button/coin cell batteries of type CR2450
- e) The nominal voltage of the button/coin cell batteries is +3V.
- f) Non-rechargeable batteries are not to be recharged.
- g) Do not force discharge, recharge, disassemble, heat above 60°C/140°F
- or incinerate. Doing so may result in injury due to venting, leakage of explosion resulting in chemical burns.

Ensure the batteries are installed correctly according to polarity (+ and Do not mix old and new batteries, different brands or types of batteries such as alkaline, carbon-zinc, or rechargeable batteries.

Remove and immediately recycle or dispose of batteries from equipment not used for an extended period of time according to local regulation Always completely secure the battery compartment. If the battery compartment does not close securely, stop using the product, remove the batteries, and keep them away from children.

Operating Temperature: -20°C (-4°F) ~ 60°C (140°F)

Keep the device away from water, fire, humidity or hot environments. Do not attempt to disassemble, repair, or modify the device. If you need service, please contact us.

Do not use the device where wireless devices are not allowed. Please read and follow the above safety information when operating the device. We cannot guarantee that no accidents or damage will occur due to improper use of the device. Please use this product with care and operate at your own risk.

P-I ink hereby declares that the device is in compliance with the essential requirements and other relevant provisions of directives 2014/53/EU, 2011/65/EU and (EU) 2015/863. The original EU declaration of conformity may be found at

https://www.tapo.com/en/support/ce TP-Link hereby declares that the device is in compliance with the

essential requirements and other relevant provisions of the Radio Equipment Regulations 2017

The original UK declaration of conformity may be found at

https://www.tapo.com/support/ukca/ For EU/UK Region:

Operating Frequency / Nominal Operating Frequency / Max Output

863~865MHz / 863.35MHz / 25mW (e.r.p)

863~865MHz / 864.35MHz / 25mW (e.r.p) 868~868.6MHz / 868.35MHz / 25mW (e.r.p)







For technical support, user guides, warranty and more. please visit https://www.tapo.com/support/



## Option 3: Use 3M Adhesives

a. Stick the included 3M adhesives to the back panel.

